




































1		2		 POWER		
3		4	<div><div>Normal</div><div>Macro</div></div>	5	 <div></div>	
6						
7						
8	<div></div>				 Windows	

9	<div><div></div><div><div>PC Connection</div><div>Mass Storage</div><div>PC Camera</div></div><div></div><div><div>PC Connection</div><div>Mass Storage</div><div>PC Camera</div><div></div></div></div>	PC
10	<div></div> <div></div>	
11	<div><div><div>Found New Hardware Wizard</div><div></div><div>Welcome to the Found New Hardware Wizard</div><div>This wizard helps you install software for: TRUST 950 POWERCOM ZOOM</div><div> If your hardware came with an installation CD or floppy disk, insert it now.</div><div>What do you want the wizard to do?</div><div><input checked="" type="radio"/> Install the software automatically (Recommended)</div><div><input type="radio"/> Install from a list or specific location (Advanced)</div><div>Click Next to continue.</div><div><div>&lt; Back</div><div>Next &gt;</div><div>Cancel</div></div></div></div> <div><div><div>Found New Hardware Wizard</div><div></div><div>Completing the Found New Hardware Wizard</div><div>The wizard has finished installing the software for: TRUST 950 POWERCOM ZOOM</div><div>Click Finish to close the wizard.</div><div><div>&lt; Back</div><div>Finish</div><div>Cancel</div></div></div></div> <div></div>	
12	<div><div><div>Removable Disk (I:)</div><div>Windows can perform the same action each time you insert a disk or connect a device with this kind of file:</div><div>Pictures</div><div>What do you want Windows to do?</div><div><div> Print the pictures using Photo Printing Wizard</div><div> View a slideshow of the images using Windows Picture and Fax Viewer</div><div> Copy pictures to a folder on my computer using Microsoft Scanner and Camera Wizard</div><div> Open folder to view files using Windows Explorer</div></div><div><input type="checkbox"/> Always do the selected action.</div><div><div>OK</div><div>Cancel</div></div></div></div> <div><div><div>Removable Disk (I:)</div><div>File and Folder Tasks</div><div>Make a new folder</div><div>Publish this folder to the Web</div><div>Share this folder</div><div>Other Places</div><div>My Computer</div><div>My Documents</div><div>Shared Documents</div><div>My Network Places</div><div>Details</div><div>DCIM</div><div>100C300</div><div>Picture Tasks</div><div>View as a slide show</div><div>Order prints online</div><div>Print pictures</div><div>Copy all items to CD</div><div>File and Folder Tasks</div><div>Make a new folder</div><div>Publish this folder to the Web</div><div>Share this folder</div><div>Other Places</div><div>Removable Disk (I:)</div><div>My Documents</div><div>Shared Documents</div><div>My Computer</div><div>My Network Places</div><div>Details</div><div>PC_0014</div></div></div> <div></div> <div></div>	<div></div> <div>Windows</div>