



www.trust.com/21865/faq


Trust



GXT 795 | UPS
POWER




1. Connecting 1/2




⚠ Always connect to grounded wall socket ⚠

2. Connecting 2/2


⚠ 720W MAX!



3. Switching On





4. Power Outage



⚠ Save your documents and shut down the computer urgently!!! ⚠

Fuse replacement 12A/250V



⚠ **ERROR!**
Short circuit / Overload

⚠ **NO WALL POWER**

✅ **WALL POWER OK**

