


Trust.



VOXXON USER GUIDE


800VA UPS

Bedienungsanleitung | Mode d'emploi | Gebruikershandleiding | Manuale utente | Manual del usuario | Guia do utilizador | Brukerveiledning
Bruksanvisning | Käyttöopas | Brugsvejledning | Instrukcja obsługi | Návod k použití | Návod na používanie | Használati útmutató | Manual de
utilizare | Ръководство за потребителя | Εγχειρίδιο χρήσης | Kullanıcı kılavuzu | Руководство пользователя | Uporabniški priročnik | Korisnički
priručnik | Guia do usuário | Посібник користувача | Naudojimo instrukcija | Kasutusjuhend | Lietošanas pamācība | מדריך למשתמש

1.

RECHARGE THE UPS


UPS aufladen | Rechargez l'UPS | Ricarica l'UPS | Recargue el UPS | Naładuj UPS



2.

CONNECT TO WALL POWER AND POWER ON



Mit der Steckdose verbinden und einschalten | Branchez à la prise murale et mettez sous tension | Collega all'alimentazione di rete e accendi | Conecte a la toma de corriente y encienda el dispositivo | Podłącz do gniazdka i włącz zasilanie



3.

WALL POWER MODE (AC MODE)




Netzstrom-Modus (AC-Modus) | Mode alimentation secteur (mode CA)
Modalità alimentazione di rete (modalità CA) Modo alimentación de red (modo CA) | Tryb zasilania sieciowego (tryb AC)



4.

BATTERY MODE (BATT MODE)



Akkumodus (Akku-Modus) | Mode batterie (mode batt) | Modalità batteria (modalità batt) | Modo batería (modo batt) | Tryb baterii (tryb batt)



5.

UPS IS OVERLOADED >480W

USV überlastet >480W | UPS surchargé >480W | UPS sovraccarico >480W
SAI sobrecargado >480W | UPS przeciążony >480W




>480W



6.

REPLACE THE FUSE - [TRUST.COM/26308/FAQ](https://www.trust.com/26308/FAQ)

Ersetzen Sie die Sicherung | Remplacez le fusible | Sostituire il fusibile | Reemplace el fusible | Wymień bezpiecznik



New fuse is not included | Neue Sicherung ist nicht im Lieferumfang enthalten | Le fusible de remplacement n'est pas inclus
Il fusibile di ricambio non è incluso | No se incluye fusible de repuesto | Nowy bezpiecznik nie jest dołączony

your work • your way

FAQ

[WWW.TRUST.COM/26308/FAQ](https://www.trust.com/26308/FAQ)

Trust International B.V. - Laan van Barcelona 600 - 3317DD, Dordrecht, The Netherlands
©2027 Trust All rights reserved.