**M**Trust

# BT-2210Tp Bluetooth 2.0 EDR USB Adapter

#### Product information

Adapter

i | A:

A: USB plug protective cap

B: Status LED Lit continuously: On Flashing: Bluetooth activity

C: USB extension cable

### Installation

- 1 Turn on the PC and insert the Trust installation CD-ROM into the CD-ROM drive.
- 2 Close all other programs and select "Install driver".
- 3 Click "Next" until window 4 appears.
- 4 Click "OK".
- 5 A window will be displayed which requests you to connect the adapter. Do not press the buttons.
- 6 Connect the Bluetooth adapter to a USB port. If necessary, use the USB extension cable.
  - A: If a window is displayed which states that the driver is not digitally signed, click "Next".
  - 7 B: Click "Finish". If the Bluetooth icon in the task bar appears red, then see the Troubleshooting section.
  - 8 If you are requested to restart the computer, select "Yes".

#### Configuration

- 9 Double-click the Bluetooth icon in the taskbar
- 10 Click "Next".
- 11 Enter a different computer name (optional) and click "Next".

  Select "Services" (optional) and click "Next". You will now have to wait. If requested, do not restart the
- 12 A Some
  - ⚠ Some services can only be selected if the required hardware (such as a modem) is present in the system.
- 13 Click "Skip".
- 14 Click "Finish". If requested, restart the computer.

### Connecting to other devices

- 15 If necessary, make the other Bluetooth device detectable (press the connect button for a couple of seconds). Also see the instruction manual provided with the device.
- 16 Double-click the Bluetooth icon in the taskbar. My Bluetooth Locations will be opened.
- 17 Click "Search for devices in range".
- 18 Double-click the desired device.
- 19 Double-click the desired service.
- 20 Click in the "Bluetooth PIN code Required" window.

A: Enter the device's PIN code. PIN code information (may be different):

21	Pairing with device type	PIN code	
21	GSM, Computer, Pocket PC	Enter an arbitrary code for both devices. These must be	

# BT-2210Tp Bluetooth 2.0 EDR USB Adapter



Various devices (headsets,		Enter the PIN code stated on the device or in the	
	modems, printers)	instruction manual. Common codes are: 1234, 0, 0000	
	Mice and keyboards	Usually do not require a PIN code.	

## B: Click "OK".

⚠ In some cases, a button on the device must be pressed in order to accept a connection.

22 The icon for the device will now be green with two arrows. You can now use the device.

# Note

## ⚠ Connecting

- The method of pairing and the use of Bluetooth may differ for different devices. See the instruction manual provided with your other Bluetooth device for the correct method.
- Bluetooth devices only remain discoverable for a limited time. If necessary, make the device discoverable again.
- The Bluetooth Adapter can be paired with a maximum of 7 different devices.

# A Profiles

- In order to be able to use a certain function, the profile concerned must be supported by both devices.
- For support for the latest profiles, download the most recent driver from www.trust.com/14693.
- For optimal Bluetooth profile support, mobile telephones must have the latest firmware update from the manufacturer.
- For more information concerning Bluetooth and supporting profiles, please see: http://www.trust.com/service/help/bluetooth.
- See the instruction manual included on the CD-ROM for detailed profile information.

# ⚠ Use

- When transferring files via Bluetooth, the files will usually be located in "My Documents\Bluetooth Exchange Folder".
- Do not carry out a number of intensive Bluetooth activities, such as transferring files and listening to high quality audio via a headset, at the same time.



# ⚠ Wireless performance

- Tips for the best wireless performance
  - Use the extension cable to move the adapter to a different location.
  - Replace or recharge the batteries of the connected devices.
  - Avoid having other wireless devices close by.
  - Avoid having concrete walls or metal objects between the adapter and the device.
- · The file transfer speed is reduced for larger files.
- Range

	Pairing with device class	Maximum range in free space
	Bluetooth Class I	100 m
	Bluetooth Class II	10 m
	Bluetooth Class III	1 m



## Troubleshooting

- . If the Bluetooth icon remains red, uninstall the Bluetooth software and remove the adapter from the USB port. Restart the computer and follow the installation procedure from step 1.
- If there is a fault when listening to high quality audio via a headset or when transferring video files, stop other intensive Bluetooth activities, such as transferring files and, if necessary, reduce the distance.
- If a headset does not produce a sound, check whether the headset has been selected as the default audio device: Control Panel - Sound and Audio Devices- Audio tab.

Go to www.trust.com/14693 for up-to-date FAQs, drivers and instruction manuals. For extensive service register at www.trust.com/register



# ⚠ Safety instructions

- · Never open or repair this device yourself.
- . Do not use the device in a damp environment. Clean the device with a dry cloth.



 This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14693/ce.



• If possible, dispose of the device at a recycling centre. Do not dispose of the device with the household waste.

### Wireless

. This class 2 wireless device works at a frequency of 2.4 GHz. It meets the essential requirements and other relevant conditions of R&TTE Directive 1999/5/EC It can be used in the following countries: all EU countries, as well as RU, TR, NO and HU. There are no limitations per channel for the above-

## BT-2210Tp Bluetooth 2.0 EDR USB Adapter



mentioned countries. Go to www.trust.com/14693 for an updated list of the countries where the use of this device is permitted.

- There may be restrictions for the use of this device outside of the EU. If this device is used outside of the EU, check whether this device meets the local regulations. Frequency: 2.4 ~ 2.4835 GHz. Bandwidth: approx. 1 MHz; Power: 20 mW.
- Be careful when using this wireless device if you have a pacemaker or are dependent on other lifesaving, sensitive electronic equipment, because this device transmits radio signals.

### Warranty & copyright

- This device has a two-year product warranty which is valid from the date of purchase. Go to www.trust.com/warranty for more information.
- It is forbidden to reproduce any part of this instruction manual without the permission of Trust International B.V.